

Install the tutorial of (2280、 22110PCIE SATA M2 Hard disk dual fan radiator)

Install tutorial

安装教程



1.Remove the label on the hard disk drive to prevent poor heat dissipation



2.Paste thermal grease to one side of the hard disk



3. Slowly push the hard disk into the heat sink
(Please notice the connecting finger and the fixed gap
need to stay outside of the slot)



4. Paste thermal grease on the other side
(In the case of a hard disk with a chip on both sides, select one side
to apply the 0.5mm gray gasket.)



5. Install the red position screws in the picture, the installation is complete