

msi GTX1080Ti Gaming X GPU Water Block

BS-MSG1080T-PA




Remove the red position screw

①




Remove the two screws on the side at the same time

①-②




Remove the original radiator

②



Clean up and reapply GPU core thermal grease

③




In the water block floor with good thermal grease

④



Attention to red position screw for installation drawing

⑤



installation is complete